



**NOTES:**

1. BENT SHEET METAL CORNER MUST BE OF SUFFICIENT GAUGE AND SECURED TO THE DECK AND WALL SUFFICIENTLY TO PREVENT BUCKLING.
2. FLEX-FLASH UN MUST BE USED TO REINFORCE MM6125 OVER THE BENT METAL CORNER.
3. METAL SUBSTRATE REQUIRE ROUGHENING/SANDING, IN ADDITION TO WIPING W/SURFACE CONDITIONER FOR PROPER ADHESION OF MM6125. ALSO, IT MUST BE FREE OF ALL OIL AND RUST.
4. HYDROSEAL 1K MUST EXTEND 4" MIN. ONTO THE APPROVED SUBSTRATE BEYOND THE MM6125 TERMINATION.
5. REFER TO DETAIL HS1K-1 FOR THE PROPER APPLICATION OF HYDROSEAL 1K



**Monolithic  
Membrane  
6125-FR**  
WITH HYDROSEAL 1K

**TYPICAL PARAPET  
AT PRECAST WALL**

**SCALE: NONE  
DATE: 06/08/23**

**HS1K-5C**

**AMERICAN HYDROTECH, INC.**