



TOP OF SLOPE ATTACHMENT
 TENDON STOP ASSEMBLY
 ROOF PARAPET
 GARDNET TENDON
 GARDNET GEOWEB SECTION



PLAN VIEW



SECTION A-A

GARDMAT EROSION BLANKET (FOR PLUGS) OR INSTAGREEN CARPET, TILE OR LAWN SOD
 LITETOP ENGINEERED GROWING MEDIA - OVERFILL GARDNET 1/2" - 1"
 GARDNET SECTION
 GARDNET TENDON CABLE
 HYDRODRAIN 300
 STYROFOAM INSULATION
 HYDROFLEX RB II
 MM 6125-FR

NOTES:

1. IF STYROFOAM INSULATION IS NOT INSTALLED, HYDRODRAIN 302 SHALL BE PLACED ON TOP OF THE HYDROFLEX RB II.
2. THE NUMBER OF STOPS AND THE SIZE, NUMBER, SPACING AND LENGTH OF REQUIRED TENDONS IS DETERMINED BY MEDIA DEPTH AND DEGREE AND LENGTH OF SLOPE.
3. TOP OF SLOPE ATTACHMENT PULL-OUT STRENGTH AND METHOD OF ATTACHMENT MUST BE DETERMINED, DESIGNED, AND VERIFIED BY THE PROJECT ARCHITECT / ENGINEER.
4. PRIOR TO SHIPPING GARDNET MATERIALS, PROJECT ARCHITECT / ENGINEER MUST PROVIDE HYDROTECH A SIGNED AND SEALED CONSTRUCTION DETAIL INDICATING GARDNET ATTACHMENT TO BUILDING STRUCTURE.
5. LITETOP MEDIA MUST BE USED IN ALL GARDNET INSTALLATIONS. SUBSTITUTIONS ARE NOT ALLOWED.



**GARDEN
 ROOF
 ASSEMBLY**

AMERICAN HYDROTECH, INC.

GARDNET - GENERAL

SCALE: NONE
 DATE: 8/17/2020

GN-2